Table of Contents

REF: Body Parts - Sub-30R	3
Linkage Mods	3
Gun Barrel Spacer for the Shifter linkage	3
Make Your Own Shifter Link	3

Last update: 2024/01/09 21:40

https://sportsterpedia.com/ Printed on 2025/10/11 03:54

2025/10/11 03:54 REF: Body Parts - Sub-30R

Go To Technical Menu

REF: Body Parts - Sub-30R

Linkage Mods

Gun Barrel Spacer for the Shifter linkage

Here is a muzzle loading rifle barrel that was drilled, then a bronze sleeve was inserted to hook up the shifter linkage when forwards were installed on a 1979 Roadster ¹⁾



Make Your Own Shifter Link

Here is a shifter link made from (304) stainless steel. 2) 3)

You can cut the threads by hand (or even better on a lathe).

Be sure to buy more length than you need to practice on.

Stainless is not easy to thread, especially by hand.

If you're going to cut threads in stainless steel, even the 'free machining' 303 grade, you want some fairly good quality dies.

Homemade stainless steel shifter linkage. 4)

Last update: 2024/01/09 21:40







Go To Technical Menu

1)

photo by sltm1 of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/191801-a-little-out-of-the-box-thinking?threadid=2046745

2) 4

Folkie of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/efi-sportster-motorcycle-talk-2007-and-up/56389-forward-control-extensions?t=286387

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/efi-sportster-motorcycle-talk-2007-and-up/56389-forward-control-extensions/page3?t=286387&page=3

From:

https://sportsterpedia.com/ - Sportsterpedia

Permanent link:

https://sportsterpedia.com/doku.php/techtalk:ref:body30r

Last update: 2024/01/09 21:40

