

CLASSIC KING TOUR-PAK

Changes have been made to the Classic King Tour-Pak cover hinge and brace hardware. The changes were made to prevent accidental loss of the hinge pins and loosening of rivets that secure the brace to the cover and box. Tighter fitting roll pins instead of the straight brass pins are now being used in the hinges along with larger size rivets for the hinge brackets.

It is recommended that these changes be made to all Classic King Tour-Paks, sold or in stock. The following parts and instructions are required to complete the change.

<u>Qty.</u>	<u>Description</u>
2	Roll pin p/n 53428-80A
6	Rivet p/n 8211
8	Washer p/n 6335

1. See Figure 1. Remove the brace assembly from the box and cover by drilling out the four pop-rivets using drill and 1/8" bit. Retain

the backing plates for later use. Remove brace from brackets the same way.

2. See Figure 2. Reinstall brace to brackets by placing washers as shown in figure and securing with a rivet.




Figure 2.

3. See Figure 3. Install new hinge pins, p/n 53428-80A, by using new pins to drift out old pins.



Figure 1.




Figure 3.

(OVER)

