

October 25, 2004

Automatic VIN Detection

If you have ever replaced an ECM with one from another bike and then used Digital Technician to Auto Detect the VIN you have probably noticed the VIN that shows up is from the motorcycle the ECM was removed from. You will want to change the VIN to correctly match the motorcycle it is installed on. This can be accomplished using Digital Technician.

1. Manually enter the VIN from the motorcycle in the Vehicle Select screen in Digital Technician. Once mileage is entered, click the green checkmark.
2. Perform a Reflash with the appropriate OEM stock, CVO, or Stage calibration. NOTE: Downloading chargeable CVO and Stage calibrations to correct the VIN will not qualify for warranty and will be billed. If you feel you need to replace an ECM with a CVO or Stage calibration you may call Technical Service before you replace the ECM for additional diagnostic assistance.
3. After the Reflash is complete the VIN will be accurate and the Auto Detect function will recognize the correct VIN for the motorcycle.