



# INSTRUCTIONS

-J00616

REV. 7-22-96

*Kit Number 66996-85T*

## SPEEDOMETER DRIVE CABLE BOOT (U.S. PATENT # D294,486)

### General

This cable boot is for use on all Harley-Davidson motorcycles equipped with a speedometer drive unit mounted on the front wheel.

### Installation

1. Loosen the speedometer cable nut at back of speedometer and unscrew the cable from the drive unit.
2. Lubricate end of cable and slide boot (small end first) onto cable at drive unit.
3. Screw cable back into drive unit and tighten cable nut at back of speedometer.
4. Slide the cable boot over the drive unit end. Boot should fit snugly against drive unit.



# INSTRUCTIONS

-J00616

REV. 7-22-96

*Kit Number 66996-85T*

## SPEEDOMETER DRIVE CABLE BOOT (U.S. PATENT # D294,486)

### General

This cable boot is for use on all Harley-Davidson motorcycles equipped with a speedometer drive unit mounted on the front wheel.

### Installation

1. Loosen the speedometer cable nut at back of speedometer and unscrew the cable from the drive unit.
2. Lubricate end of cable and slide boot (small end first) onto cable at drive unit.
3. Screw cable back into drive unit and tighten cable nut at back of speedometer.
4. Slide the cable boot over the drive unit end. Boot should fit snugly against drive unit.