



INSTRUCTIONS

-J00623

REV. 2-1-92

Kit Number 54490-92T

SHOCK ABSORBER KIT WITH WASHERS

General

This kit is designed for installation on all 1956 to 1978 XL model vehicles.

These shock absorbers are designed to replace the original equipment units on 1975 to 1978 XL model vehicles.

This kit may also be used on 1956 to 1974 models XL's when used in conjunction with Conversion Kit Part No. 54529-76 (two required for installation).

This kit contains the following components:

QTY	DESCRIPTION
2	Washer, flat, 3/8 in.
6	Washer, flat, 1/2 in.
2	Shock Absorber

NOTE

There are no service parts for this kit.

Installation

1. See instructions in appropriate Service Manual or on Conversion Kit (Part No. 54529-76), if required, for installation procedures.

NOTE

If you have purchased Conversion Kit Part No. 54529-76 to be used with XL models 1956-74, discard washers found with Conversion Kit and use washers included with Shock Absorber Kit.

CAUTION

The flat washers supplied in the kit must be used to allow shock absorber to pivot. The flat washers will help prevent premature wear of the shock absorber mounting eye. Use only washers included with this kit.



INSTRUCTIONS

-J00623

REV. 2-1-92

Kit Number 54490-92T

SHOCK ABSORBER KIT WITH WASHERS

General

This kit is designed for installation on all 1956 to 1978 XL model vehicles.

These shock absorbers are designed to replace the original equipment units on 1975 to 1978 XL model vehicles.

This kit may also be used on 1956 to 1974 models XL's when used in conjunction with Conversion Kit Part No. 54529-76 (two required for installation).

This kit contains the following components:

QTY	DESCRIPTION
2	Washer, flat, 3/8 in.
6	Washer, flat, 1/2 in.
2	Shock Absorber

NOTE

There are no service parts for this kit.

Installation

1. See instructions in appropriate Service Manual or on Conversion Kit (Part No. 54529-76), if required, for installation procedures.

NOTE

If you have purchased Conversion Kit Part No. 54529-76 to be used with XL models 1956-74, discard washers found with Conversion Kit and use washers included with Shock Absorber Kit.

CAUTION

The flat washers supplied in the kit must be used to allow shock absorber to pivot. The flat washers will help prevent premature wear of the shock absorber mounting eye. Use only washers included with this kit.