



INSTRUCTIONS

-J01552

REV. 4-15-99

Kit Number 48436-00

CHROME SPORTSTER SWINGARM

General

This swingarm (rear fork) fits all 2000 Sportster model motorcycles.

Kit contents:

QTY	DESCRIPTION	PART NUMBER
1	Rear, Fork Chrome	48437-00

NOTE

To install this rear fork a Sportster Service Manual for your particular year motorcycle is required. A Service Manual can be purchased from your Harley-Davidson dealer.

Installation

Follow the instructions given in the **Rear Fork** section of your Service Manual to remove and install the rear wheel, rear brake caliper, rear shock absorber nuts, rear belt guard and debris deflector, and rear fork. The rear fork in this kit installs in the same way as the original equipment rear fork.

Pay close attention to all warnings, cautions, and torque specifications when installing this rear fork.



INSTRUCTIONS

-J01552

REV. 4-15-99

Kit Number 48436-00

CHROME SPORTSTER SWINGARM

General

This swingarm (rear fork) fits all 2000 Sportster model motorcycles.

Kit contents:

QTY	DESCRIPTION	PART NUMBER
1	Rear, Fork Chrome	48437-00

NOTE

To install this rear fork a Sportster Service Manual for your particular year motorcycle is required. A Service Manual can be purchased from your Harley-Davidson dealer.

Installation

Follow the instructions given in the **Rear Fork** section of your Service Manual to remove and install the rear wheel, rear brake caliper, rear shock absorber nuts, rear belt guard and debris deflector, and rear fork. The rear fork in this kit installs in the same way as the original equipment rear fork.

Pay close attention to all warnings, cautions, and torque specifications when installing this rear fork.