



INSTRUCTIONS

-J01586

REV. 6-10-99

Kit Numbers 46123-99, 46120-99

MOTORCYCLE ANCHOR

General

These kits are designed to be used with all model motorcycles. Kit 46123-99 is a large motorcycle anchor kit. Kit 46120-99 is a smaller motorcycle anchor kit.

NOTE

The motorcycle anchor should be attached to cement, concrete, brick or solid block with the sleeve anchor bolts supplied in the kit.

Kit contents

- 1 motorcycle anchor
- 1 anchor base cover
- 3 sleeve anchor bolts

Installation

1. Place the baseplate in desired location and mark the location of the three holes in the baseplate. Remove baseplate and carefully drill holes using a 1/2" (12 mm) masonry drill bit.

2. Insert the sleeve anchor bolts through the baseplate and carefully tap into position. Tighten the bolts firmly with a socket wrench.
3. Place the cover over the baseplate and thread your chain or cable lock through the vehicle (the motorcycle's motor, chassis, or gearbox) and back to the motorcycle anchor. Now padlock the chain, or secure the cable lock to the bolt-down.

NOTE

Adapter ring 46168-99 may be used with the large motorcycle anchor for a tighter fit with cable locks or high shackle padlocks. This kit is available separately from your Harley Davidson Dealer.

Relocation Instructions

1. Remove the padlock or cable lock, remove the cover, then loosen the anchor bolts nuts with a socket wrench.
2. Remove the baseplate.
3. Reinstall the Motorcycle Anchor Kit using three new sleeve anchor bolts following installation instructions above.



INSTRUCTIONS

-J01586

REV. 6-10-99

Kit Numbers 46123-99, 46120-99

MOTORCYCLE ANCHOR

General

These kits are designed to be used with all model motorcycles. Kit 46123-99 is a large motorcycle anchor kit. Kit 46120-99 is a smaller motorcycle anchor kit.

NOTE

The motorcycle anchor should be attached to cement, concrete, brick or solid block with the sleeve anchor bolts supplied in the kit.

Kit contents

- 1 motorcycle anchor
- 1 anchor base cover
- 3 sleeve anchor bolts

Installation

1. Place the baseplate in desired location and mark the location of the three holes in the baseplate. Remove baseplate and carefully drill holes using a 1/2" (12 mm) masonry drill bit.

2. Insert the sleeve anchor bolts through the baseplate and carefully tap into position. Tighten the bolts firmly with a socket wrench.
3. Place the cover over the baseplate and thread your chain or cable lock through the vehicle (the motorcycle's motor, chassis, or gearbox) and back to the motorcycle anchor. Now padlock the chain, or secure the cable lock to the bolt-down.

NOTE

Adapter ring 46168-99 may be used with the large motorcycle anchor for a tighter fit with cable locks or high shackle padlocks. This kit is available separately from your Harley Davidson Dealer.

Relocation Instructions

1. Remove the padlock or cable lock, remove the cover, then loosen the anchor bolts nuts with a socket wrench.
2. Remove the baseplate.
3. Reinstall the Motorcycle Anchor Kit using three new sleeve anchor bolts following installation instructions above.