



INSTRUCTIONS

-J02038

REV. 7-14-00

Kit Number 50137-95, 50156-95, 50168-95 and 50169-95

FOOTPEG REPAIR KITS

General

Kit 50137-95 fits Part No. 50134-95; Kit 50156-95 fits Part No. 50133-95; Kit 50168-95 fits Part No. 50130-95; Kit 50169-95 fits Part No. 50131-95.

Kit Contents:

Kit 50137-95

ITEM	DESCRIPTION	PART NO.
1	Tread, rubber	50138-95
2	Tread, rubber	50139-95
3	Tread, rubber	50140-95
4	Tread, rubber	50141-95
5	Tread, rubber	50142-95
6	LOCTITE 380, black max, tube	99840-00

Kit 50156-95

ITEM	DESCRIPTION	PART NO.
1	Tread, rubber	50157-95
2	Tread, rubber	50158-95
3	Tread, rubber	50159-95
4	Tread, rubber	50160-95
5	Tread, rubber	50161-95
6	LOCTITE 380, black max, tube	99840-00

Kit 50168-95

ITEM	DESCRIPTION	PART NO.
1	Tread, center	50152-95
2	Tread, outer (2)	50153-95
3	LOCTITE 380, black max, tube	99840-00

Kit 50169-95

ITEM	DESCRIPTION	PART NO.
1	Tread, center	50150-95
2	Tread, outer (2)	50151-95
3	LOCTITE 380, black max, tube	99840-00

Removal of Worn Treads

CAUTION

Be careful when removing treads not to scratch chrome components.

1. Place narrow pry bar or screw driver between rubber tread and footpeg casting. Peel tread away from footpeg casting. Take care not to damage adhesive/locator pins cast underneath tread.
2. Scrape away residual rubber, adhesive and debris from all surfaces.
3. Repeat steps 1 and 2 for all treads requiring replacement prior to installing new treads.

Installation

1. Determine location and orientation of each replacement tread.
2. Apply a conservative amount of adhesive (included in kit) to the bottom side and hole of tread. If too much adhesive is used, it will ooze out from under tread and cause an unsightly mess!
3. Place tread in proper location of footpeg casting and apply pressure sufficient for it to fully seat on pins. (Press hard directly over each pin.)
4. Repeat for all treads on a single peg.
5. Apply constant pressure to treads to properly bond.

NOTE

One method is to tightly wrap the footpeg with duct tape. Prior to wrapping, place something between the footpeg and tape so it does not leave a residue on the footpeg (A large piece of duct tape folded onto itself works well.)

6. Allow adhesive to cure for 24 hrs.
7. Remove tape.