

# Parts & Accessories Bulletin

February 20, 1987

P & A# 332



## Mid 1987 FLST Special Edition Unique Parts Listing

This P & A Bulletin covers the unique parts on the mid-year (1987-1/2) FLST Special Edition. Refer to the 1987 FLST Model and the 1987 FXSTC (engine and transmission) parts listing in Parts Catalog 1987 1340 Models, Part No. 99450-87, for all other parts on the FLST Special Model. This bulletin includes all painted parts in the "PAINTED PARTS" section found at the end of the part listing. Additional copies of this bulletin are available from the Technical Communications Department. Please specify P & A # 332 and quantity in your written request.

### SEATS & SISSY BAR

868	SCREW, solo seat	Late 87 - FLST SP.
1000	SCREW, backrest (2)	Late 87 - FLST SP.
1602	SCREW, concho	Late 87 - FLST SP.
1357W	SCREW, backrest	Late 87 - FLST SP.
2607	SCREW, backrest (2)	Late 87 - FLST SP.
3568	SCREW, solo seat, (2)	Late 87 - FLST SP.
3767B	BOLT, pass. seat (2)	Late 87 - FLST SP.
3974HW	BOLT, pass. seat (2)	Late 87 - FLST SP.
6333	WASHER, pass. seat	Late 87 - FLST SP.
6516HW	WASHER, pass. strap (2)	Late 87 - FLST SP.
7036	LOCKWASHER, pass. seat (2)	Late 87 - FLST SP.
7068	LOCKWASHER, solo seat (2)	Late 87 - FLST SP.
51185-87	PASSENGER STRAP	Late 87 - FLST SP.
51652-83	BRACKET, seat	Late 87 - FLST SP.
52208-86	PASSENGER SEAT KIT	Late 87 - FLST SP.
52236-86	SOLO SADDLE KIT	Late 87 - FLST SP.
52508-87	SPACER, solo seat (2)	Late 87 - FLST SP.
52541-87	BACKREST & CONCHO KIT	Late 87 - FLST SP.
52658-86	SISSY BAR ASSEMBLY	Late 87 - FLST SP.
52771-82	BRACKET, backrest	Late 87 - FLST SP.
91850-87	CONCHO	Late 87 - FLST SP.

### WINDSHIELD - KING SIZE

2430	SCREW, windshield to adj. brkt. (2)	Late 87 - FLST SP.
2725	SCREW, windshield (7)	Late 87 - FLST SP.
7030W	LOCKWASHER, windshield (9)	Late 87 - FLST SP.
7651	NUT, acorn - inner brace (5)	Late 87 - FLST SP.
7654W	NUT, adj. brkt. (4)	Late 87 - FLST SP.
58075-86	WINDOW, adjustable	Late 87 - FLST SP.
58078-49	ADJUSTABLE BRACKET, right	Late 87 - FLST SP.
58079-49	ADJUSTABLE BRACKET, left	Late 87 - FLST SP.
58183-78	WINDOW	Late 87 - FLST SP.



## PASSING LAMPS & TURN SIGNALS

2647	SCREW, turn signal mtg.	Late 87 - FLST SP.
3960W	BOLT, bottom windshield mtg. (2)	Late 87 - FLST SP.
4020W	BOLT, bottom passing lamp brkt. (2)	Late 87 - FLST SP.
4036	BOLT, top windshield mtg. (2)	Late 87 - FLST SP.
5885	SPACER, bottom windshield mtg. (2)	Late 87 - FLST SP.
6645	WASHER, windshield & brkt. mtg. (6)	Late 87 - FLST SP.
7041	LOCKWASHER, windshield & brkt. mtg. (6)	Late 87 - FLST SP.
7069	LOCKWASHER, turn signal mtg.(4)	Late 87 - FLST SP.
7778	LOCKNUT, passing lamp mtg. (2)	Late 87 - FLST SP.
9900	WIRE TERMINAL, connector	Late 87 - FLST SP.
10006	CABLE STRAP, Wire to fork brkt.	Late 87 - FLST SP.
10039	CABLE STRAP, passing lamp harness	Late 87 - FLST SP.
10065	CABLE STRAP, wiring harness	Late 87 - FLST SP.
58082-87	MOUNTING BRACKET, windshield & passing lamps	Late 87 - FLST SP.
67615-87	WIRING HARNESS, passing lamps	Late 87 - FLST SP.
67821-87	BACK PANEL, left rear - fork	Late 87 - FLST SP.
67844-70	TOGGLE SWITCH, passing lamps	Late 87 - FLST SP.
67846-70	NUT, toggle switch	Late 87 - FLST SP.
68163-84	BULB, turn signal (2) (HDI only)	Late 87 - FLST SP.
68165-64	BULB, turn signal (2)	Late 87 - FLST SP.
68440-86	LENS, turn signal (2)	Late 87 - FLST SP.
68451-86	O-RING, turn signal lens	Late 87 - FLST SP.
68452-86	SCREW W/O-RING, turn signal lens (2)	Late 87 - FLST SP.
68519-68	BRACKET, turn signal mtg.	Late 87 - FLST SP.
68619-83	LABEL, passing lamps	Late 87 - FLST SP.
68660-87	PASSING LAMPS (2)	Late 87 - FLST SP.
68661-87	TURN SIGNAL, left	Late 87 - FLST SP.
68668-87	TURN SIGNAL, right	Late 87 - FLST SP.
68677-87	TURN SIGNAL, left (HDI only)	Late 87 - FLST SP.
68679-87	TURN SIGNAL, right (HDI only)	Late 87 - FLST SP.
68672-38	SCREW, passing lamp molding, (2)	Late 87 - FLST SP.
68674-69	SEALED UNIT, passing lamp (2)	Late 87 - FLST SP.
68690-69	CLIP, wire passing lamp (2)	Late 87 - FLST SP.
68720-62	CLAMP BLOCK, passing lamp (2)	Late 87 - FLST SP.
68721-82	SWIVEL BLOCK, passing lamp (2)	Late 87 - FLST SP.
68725-62	MOLDING, passing lamp (2)	Late 87 - FLST SP.
72034-71	HOUSING, double socket	Late 87 - FLST SP.
72035-71	HOUSING, double pin	Late 87 - FLST SP.
72038-71	SOCKET, single pin (2)	Late 87 - FLST SP.
72039-71	PIN, single socket (2)	Late 87 - FLST SP.
72275-74	CONNECTOR TAB, two terminal	Late 87 - FLST SP.

## SADDLEBAGS

741	CAP, support mtg. nut (4)	Late 87 - FLST SP.
2665	SCREW, reflector mtg. (2)	Late 87 - FLST SP.
2818	BOLT, brace to supports	Late 87 - FLST SP.

**SADDLEBAGS (CONT'D)**

4721	BOLT, support mtg. (4)	Late 87 - FLST SP.
5772	SPACER, brace to support	Late 87 - FLST SP.
6109	WASHER,brace to support (2)	Late 87 - FLST SP.
6379W	WASHER, saddlebag mtg. (4)	Late 87 - FLST SP.
6398	WASHER, saddlebag mtg. (rubber) (4)	Late 87 - FLST SP.
6702	WASHER, brace to support (2)	Late 87 - FLST SP.
6716	WASHER, reflector mtg.	Late 87 - FLST SP.
7069	LOCKWASHER, reflector mtg. (2)	Late 87 - FLST SP.
7739	LOCKNUT, brace to support (2)	Late 87 - FLST SP.
7778	LOCKNUT, supports (4)	Late 87 - FLST SP.
51923-86	CIRCLE CLIP, saddlebag mtg.	Late 87 - FLST SP.
59252-87	REFLECTOR, round (amber) (2) (HDI only)	Late 87 - FLST SP.
59264-86	REFLECTOR, round (red) (2)	Late 87 - FLST SP.
90640-86	SADDLEBAG, left	Late 87 - FLST SP.
90644-86	SADDLEBAG, right	Late 87 - FLST SP.
90785-86	SUPPORT, saddlebag - right	Late 87 - FLST SP.
90787-86	SUPPORT, saddlebag - left	Late 87 - FLST SP.
90820-74A	LABEL, saddlebag (2)	Late 87 - FLST SP.
90844-80	ACORN NUT, reflector mtg. (2)	Late 87 - FLST SP.
90989-63	BRACE, saddlebag - rear	Late 87 - FLST SP.

**PAINTED PARTS**

	NOTE: Metallic blue/creme.	
58934-87	FRONT FENDER	Late 87 - FLST SP.
58935-87	REAR FENDER	Late 87 - FLST SP.
61998-87	FUEL TANK, left	Late 87 - FLST SP.
61999-87	FUEL TANK, right	Late 87 - FLST SP.