



INSTRUCTIONS

-J04204

2006-05-16

SPORTSTER 50TH ANNIVERSARY TIMER COVER KIT

GENERAL

Kit Number

32886-07, 32966-07

Models

These kits fit 2004 and later XL Sportster® model motorcycles.

Kit Contents

See Figure 1 and Table 1.

INSTALLATION

⚠ WARNING

Disconnect negative (-) battery cable first. If positive (+) cable should contact ground with negative (-) cable connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury. (00049a)

⚠ WARNING

To prevent accidental vehicle start-up, which could cause death or serious injury, remove main fuse before proceeding. (00251b)

1. See Figure 1. Remove and discard the original screws and timer cover.
2. Place new timer cover (1) in position and secure with chrome screws (2).

⚠ WARNING

Connect positive (+) battery cable first. If positive (+) cable should contact ground with negative (-) cable connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury. (00068a)

SPECIAL CARE INSTRUCTIONS

NOTE

To prevent damage to the chrome surface, do not use any detergents, chemical solvents, polishes or abrasive cleaning agents.

These Chrome Sportster Timer Cover kits are chrome plated, with paint filled accents.

To keep this surface in best condition, lightly wipe with a Harley-Davidson Micro Fiber cloth, part number 94663-02, using clear water or a mild Harley-Davidson cleaner such as:

- Sunwash (part number 94659-98),
- Bug Remover (part number 94657-98) or
- Harley Gloss (part number 94627-98).

NOTE

These cleaners are available separately or as part of the Harley Care Starter Kit, part number 94671-99 from your Harley Davidson Dealer.

SERVICE PARTS




Figure 1. Service Parts: Sportster 50th Anniversary Timer Cover

Table 1. Service Parts: Timer Cover Kit

Item	Description (Quantity)	Part Number
1	Timer cover	Not Sold Separately
2	Screw, button head Torx, #8-32 UNC x .50 inch long (2)	Not Sold Separately